

**HEAT STRESS MONITOR
SOFTWARE FOR WINDOWS**

HB3215-05

IMPORTANT.

For our UK customers, service under guarantee is offered solely by the **CASELLA CEL Limited** service department. There are no UK agents or repair services authorised by us to carryout this work.

In order to ensure that only approved replacement parts are used for routine maintenance after the guarantee period, we recommend that this is carried out by our fully skilled service engineers or in the case of service required outside the UK. by our appointed agents.

USER MANUAL

HEAT STRESS MONITOR

COPYRIGHT

The copyright in this document which contains proprietary information is vested in **CASELLA CEL LIMITED**. The contents of this document must not be used for purposes other than for which it has been supplied or reproduced or disclosed wholly or in part without the prior written permission of **CASELLA CEL LIMITED**.


CASELLA CEL LIMITED

Regent House
Wolseley Road
Kempston
Bedford
MK42 7JY

Telephone: +44 (0)1234 844100
Facsimile: +44 (0)1234 841490
E-Mail: info@casella.co.uk
Webpage: <http://www.casella.co.uk>

	Page No.
CONTENTS	4
1.0 HARDWARE REQUIREMENTS	5
2.0 PROGRAM INSTALLATION	5
3.0 CONNECTING THE HSM100 TO A P.C.	6
4.0 STARTING THE PROGRAM	6
5.0 PROGRAM CONFIGURATION	6
6.0 USING HELP	6
7.0 SERIAL PORT SELECTION	6
8.0 CUSTOMISED SCREEN LAYOUTS	7
9.0 SIZE AND POSITION	7
10.0 MODIFY PARAMETERS	7
11.0 DELETING DISPLAY ELEMENTS	7
12.0 ADDING DISPLAY ELEMENTS	8
12.1 Text box	8
12.1 Date box / Time box	8
12.2 Value box	8
12.3 Bitmap box	8
12.4 Multistate box	8
12.5 Graph box	9
13.0 SCROLLING DISPLAY FEATURE	9
14.0 SAVING THE CONFIGURATION	10
15.0 GRAPH AND TABULAR DATA PRESENTATION	10
16.0 ALARMS	10
16.1 Setting the upper & lower alarm limits.	10
16.2 External alarm operation	11
16.3 Loss of data alarm	11
17.0 DATA LOGGING / COLLECTION	11
18.0 DATA INPUTS AND PROCESSED DATA	12
APPENDIX A - FORMULAE	14
WBGT CALCULATION	15

CASELLA 'HEAT STRESS MONITOR' SOFTWARE FOR WINDOWS



The Heat Stress monitor software package is a powerful and versatile program for the accumulation, processing and presentation of heat stress data.

The program integrates the functions of real time data presentation, data archiving and historical analysis within one attractive and easy to use package.

The program operates within the WINDOWS environment and provides the following features:-

- A real time display indicating prevailing heat stress conditions and trends.
- Archiving of data to disk at a user defined interval for historical analysis.
- Dynamically changing screens including scrolling graphs and alarm warnings
- Production of line graphs based upon historical data.
- Tabular report presentation of data files.
- Automatic calculation of derived values including Humidity, Vapour Pressure, and Dew Point.
- Real time display pages may be user configured to meet specific display requirements.

1.0 HARDWARE REQUIREMENTS

IBM Compatible P.C. 386 SX upwards
4MB Memory. Mouse, Spare RS232 Serial Port.
VGA or SVGA monitor. Program occupies less than 2MB.disk space.
Windows Operating System: Ver 3.1, 3.11 for Work Groups, Windows 95, NT.

2.0 PROGRAM INSTALLATION

The software will be supplied on one 3.5" floppy diskette. Insert the disk into the floppy drive.


Using windows file manager, initiate the file **INSTALL.EXE**. Follow on screen messages to load the program into the desired directory (e.g. **C:\HSM**)

Following installation, it may be necessary to adjust certain parameters such as the serial port identification to suit the hardware environment.

3.0 CONNECTING THE HSM100 TO A P.C.

The HSM 100 should be connected to a spare RS232 serial port on the P.C using the supplied cable. Please ensure that the selected port is not used for other applications and that no device drivers are loaded which may conflict with the ports use (DOS Mouse drivers, modem software etc.)

For information, the HSM100's data socket is wired as follows;



HSM CONNECTOR	IBM 9 WAY FEMALE
1 TXD	2 RXD
2 DTR	1 DCD, 6 DSR, 8 CTS
3 GND	5 GND
4 RTS	4 DTR

Data will be transmitted from the HSM100 every 1-2 seconds whilst it's RTS line (Pin4) remains high.

4.0 STARTING THE PROGRAM

To initiate the 'HSM' software, double-click the '**HSM 100**' Icon within the '**HSM for WINDOWS**' program group.

All menus and options are accessible using mouse based operations. If you are new to the Graphical user interface of the Windows environment, please refer to your Microsoft Windows documentation.

5.0 PROGRAM CONFIGURATION

Program set-up details defining the screen layout, data parameters and serial port connection are saved within a file **HSM.INI**. To prevent unauthorised operators modifying the software's configuration and thereby introducing potential problems, it is recommended that the '**HSM.INI**' file is made '**read-only**'. Whilst this file is in a read only condition, all menu options used to access editing functions are removed from menus. The read only attribute may be set from Windows '**File Manager**' or '**Explorer**'.

6.0 USING HELP

The program has been written such that the user should find the application both quick to learn and easy to use. As with all new software packages the user should spend some time experimenting and becoming familiar with menu functions. A '**Help**' '**Contents**' window provides a list of all major Help topics.

7.0 SERIAL PORT SELECTION

The program will be supplied configured to expect the HSM 100 to be connected to the P.Cs '**COM1**' serial port. The serial communication port settings can be changed by using the '**Edit Data Input**', '**Properties**', option from the main '**Options**' menu. The HSM 100 communicates at 1200 Baud, with 8 Data bits, no parity, one stop bit and no flow control.

Save any set-up changes such as the serial port details using the '**Save Configuration**' option from within the '**Options**' menu.

8.0 CUSTOMISED SCREEN LAYOUTS. (FOR SPECIALISED APPLICATIONS)

The program is supplied ready to operate with 4 display pages pre-configured to suit the vast majority of applications. Many customers may not find it necessary to customise the screen configuration. A copy of the original program diskette should be retained such that it is possible to re-load the program with its default configuration files.

The currently displayed page is selected from the '**View**' menu.

A maximum of 8 different screen configurations may be customised to suit a specific requirement. Display pages may incorporate a variety of display elements including value boxes, scrolling graphs, text messages and bit map images for the display of company logos etc.

Modification to the programs display configuration can only be carried out whilst the file '**HSM.INI**' is in a **Read/Write** mode. Use Windows '**File Manager**' or '**Explorer**' to change the properties of the supplied file from read only to read-write and then start the **HSM** program.

Simple mouse based operations enable display elements to be added, positioned, sized or deleted. To modify any on screen display elements including positions, sizes, titles, data channels, display units etc., either '**Click the right mouse button**' or select '**Edit Display**' from the '**Options**' menu.

9.0 SIZE AND POSITION

The '**Size**' and '**Position**' functions are self explanatory. Simply click and hold the left mouse button whilst located on the relevant display element and move the mouse to reposition or size the element. Release the mouse button to complete the operation.

10.0 MODIFY PARAMETERS

The '**Modify Parameters**' option is used to edit various characteristics of a display element. Position the marker on the relevant box and click the left button. Text items including titles, engineering units, fonts, borders and colours may be changed within the '**Edit Basic Parameters**' window. The '**Data**' channel identifies which input data field will be presented within the display element.

11.0 DELETING DISPLAY ELEMENTS

To delete a display element, simply position the cursor marker on the relevant display item and click the left mouse button. **NOTE:** Once an element has been removed and the new configuration saved, there is no way of recovering a deleted object.

12.0 ADDING NEW DISPLAY ELEMENTS

The following display elements are available for presentation on a real time screen;-


12.1 Text box

Used to display a fixed text message as shown below:-




12.2 Date box / Time box

Use to display Time and Date based on the P.Cs internal clock.



12.3 Value box

Use to display a data channel value together with top and bottom labels as shown below.



12.4 Bitmap box

Used to display a 16 Colour windows bitmap image file. Commonly used to display company logos, site maps, warning symbols etc.



12.5 Multistate box


Multi-state images are created using a single bit map which is subdivided horizontally into blocks of equal width. The displayed image section is dependent upon the value of a data channel. e.g.



In the battery condition example above;- the number of images should be set to 2. The 'steps' value is set to 0.5. The 'Battery Low' image will be displayed for values less than or equal to 0.5, the 'Battery O.K' image will be shown for values above 0.5. The battery status value contained within the HSM100 message is 'L' for a Low discharged battery and 'H' for a good High battery. The software automatically converts the letter 'H' to a value 1 and the letter 'L' to a value 0.

12.6 Graph box

Provides a real time scrolling graph for one or two traces over a user selectable time period.



The trace dimensions box contains values to set up the position and size of the trace area in relation to the outer box.

TRACE DIMENSIONS

35,40,400,360

In this example, the trace area starts 35 pixels to the right of the top left hand corner of the element window and 40 pixels down. The trace area is 400 pixels wide and 360 high.

13.0 SCROLLING DISPLAY FEATURE

The Heat Stress software provides up to 8 separate display pages. Each page may be selected for display from the 'View' pull down menu.

The 'Scroll' option allows the software to automatically display the pages in any sequence with a programmable delay between each page.

To enable the **scroll** mode, select '**Scroll setup**' from the '**Options**' pull down menu. Click on the Enable box to enable or disable the automatic scrolling and enter the sequence in which you want the pages to appear in the '**Order**' box.

The default time delay is fifteen seconds, however this can be changed by editing the [**Scroll**] section of the HSM.INI file.

[Scroll]

Enable=Yes

Order=1,2,3,4,

Interval=15

This will give a time delay of 15 seconds. Note that the scroll mode enable/disable and page order may also be changed here.

14.0 SAVING THE CONFIGURATION

Any modifications or additions to the programs configuration should be saved using the **'Save Configuration'** option from within the **'Options'** menu. The file **'HSM.INI'** can be made Read-Only once you are happy with the programs configuration.

To return to display mode, either press the right mouse button and select the **'Return to Display Mode'** option, alternatively, select **'Display Mode'** from the **'Options'**, **'Edit Display'** menu.

15.0 GRAPH AND TABULAR DATA PRESENTATION

Historical graphs and tables are created using the **'Historical Table'** or **'Historical Graph'** options from the **'View'** menu. All presentations utilise data files saved using the HSM software.

All presentations require selection of the required start date and times. Graphs may be used to display two different traces, the extreme values of the 'Y' axis ranges may be determined via the **'Options' 'Edit Graph Scales'** menu or alternatively by using the **'Edit Trace'** option when selecting the trace(s) to be plotted.

All presentation formats can be printed using the **'Print Window'** option within the **'File'** menu.

Data files are automatically saved as daily files using a comma separated text format which may be easily imported into many commercial spreadsheet, data base or word processing applications.

16.0 ALARMS

The Heat Stress Monitor software incorporates an ALARM facility. Any or all of the sensor channels can be used to initiate an alarm upon reaching a pre-set value.

An alarm is indicated by the appropriate value box flashing red and an audible bleep from the P.C. The title bar of the window will also flash.

16.1 Setting the upper & lower alarm limits

Click on Options and from the pull down menu select Edit Data Input.

From the sub-menu select Processed Data.

Note the Channel ID Code area and click on the Current ID button. Chose the sensor you wish to set from the displayed list.

The current alarm settings for that sensor will appear in the Alarms area. Change the Upper Alarm Limit and Lower Alarm Limit values as desired.

After you have entered the new value, click on the Save Changes button. You may now select another sensor to change or click on Done to exit. Click on Options again and select Save Configuration to save the changes you have made.

16.2 External alarm operation.

When an alarm condition exists, the DTR line of the comms port will go high and may be used to switch an external alarm using a suitable interface circuit. The comms port for the alarm may, or may not be the same one you are using for communications with the HSM100. Any serial port can be selected for the alarm output by editing the [ALARM] section of the 'HSM.INI' file.

[Alarm]
Enable=No
Port=Com1:,9600,N,8,1
DataLossEnable=Yes
DataLossInterval=60
ActiveHigh=Yes

This will cause the DTR line of serial port 1 to go high if an alarm condition exists.

The external alarm will operate for about two seconds when the 'HSM' software is first initiated. After this, a manual test may be carried out by selecting the '**Options**' - '**Alarm**' - '**Test**' option. Other alarm functions available include:-

Mute:- silences alarm but leaves the relevant display boxes flashing.
Reset:- Cancels the alarm or 'test' function.

16.3 Loss of Data Alarm

A time out period for incoming raw data may be defined by editing the '[Alarm]' section of the HSM.INI file. If the normal alarm function is disabled then so is the Loss of data alarm. The time-out interval is expressed in seconds.

When the loss of data alarm is triggered all data elements and also the title bar at the top of the screen will flash.

17.0 DATA LOGGING / COLLECTION.

The software can be used to automatically log data to the hard disk during program execution. Logging can be turned on and off via the '**Options**' - '**Logging**' menu.

The path used to save and retrieve data files is specified within the 'HSM.INI' file:-

[Logging]
Path=C:\HSM
Enable=Yes
Interval=10
Units=Minutes

18.0 DATA INPUTS AND PROCESSED DATA.

The defining of data inputs and processed data channels represents the most complex aspect of the 'HSM' software package. **Most users should have no need to edit or modify any of the data definitions.** The program will be supplied with all data inputs pre-configured to suit the HSM100 output message. Vapour pressure, dew point and humidity values are also calculated. Under normal circumstances it should not be necessary to modify any of the data definitions. The primary data input from the HSM100 is defined within the 'Edit Data Input' 'Device' 'Channels' window. The Data inputs represent the sequence of data values contained within the HSM100 message. The serial data message transmitted by the HSM100 is shown below;-

I,+021.5,+021.5,+028.7,+018.4,+028.7,M,+025.3,+025.2,+030.3,+022.7,+031.7,C,2,H

I,+021.5,+021.5,+028.7,+018.4,+028.7,M,+025.3,+025.2,+030.3,+022.7,+031.7,C,2,H

The comma separated values represent the following parameters;-

I	Instant values next
+021.5	Indoor WBGT
+021.5	Outside WBGT
+028.7	Dry Temp
+018.4	Wet Temp
+028.7	Globe Temp
M	Max values next
+025.3	Max Indoor WBGT
+0225.2	Max Outside WBGT
+030.3	Max Dry Temp
+022.7	Max Wet Temp
+031.7	Max Globe Temp
C	Degrees C used (F for Fahrenheit)
2	Globe Size
H	Battery State (H=High, L=Low)

Data obtained from the raw input 'Channels' is passed into 'Processed data' channels. Processed data channels are used to define the acceptable range of the data, high and low alarm thresholds, the data format (number of decimal places), logging units and also to provide various mathematical functions.

Functions include:-

EXTREME ([MAX/MIN])

Retains the maximum or minimum data value since reset or midnight.

Reset the extreme values using the 'Reset Parameter'  command from the 'Options' menu.

VAPOUR(HUMIDITY)

Calculates the Vapour pressure (hPa) based upon a data source containing the Temperature (°C) and the Humidity (%RH) value.

DEWPOINT()

Calculates the DEW point temperature based upon a Data source of Vapour Pressure.

HUMIDITY(WET,V,P)

Calculates a Humidity value based upon a data source of '**Dry**' bulb Temperature, a '**Wet**' bulb temperature, Ventilation and a **P**ressure constants. The '**Scale**' function is used to set the Ventilation constant to 0.000696 and the **P**ressure constant to 1000mBar.

DEGREEDAY(THRESHOLD,[ABOVE/BELOW])

An integrating function used to calculate '**Degree Day**' values. For Degree day measurement the input data source would be a temperature value. The Temperature difference above or below the '**Threshold**' is integrated with respect to time.(ie, if the temperature is 2°C above threshold for 12 hours (half a day) then the result would be 1 degree-day.

ROLLAVG(SECONDS)

Calculates the rolling average of the data input occurring over a '**Seconds**' time period.

SCALE (M, C)

Provides linear scaling of the input data source values according to the equation :-
Processed Data =Mx+C. where 'X' is the specified 'Data input' channel.

APPENDIX A - FORMULAE.

The following formulae are used to derive Humidity and Dew point values based upon measured wet and dry temperatures (Tw and Td).

The saturated vapour pressures are calculated using the MAGNUS formula (Ref. BS1339:1981-Definitions, formulae and constants relating to the humidity of air)

$$\log_{10} e_w = \frac{GT_w}{H + T_w} + I$$

Where:

e_w is the saturation vapour pressure of the air (hPa).

T_w is the air temperature (°C).

The remaining constants can have different values depending on the temperature of the wet sensor. If the sensor is below 0°C then it is deemed to be 'Over Ice' else 'Over Water'. The following constants are automatically selected by the program during operation:

	Over Water	Over Ice
G	7.5	9.5
H	237.3	265.5
I	0.78571	0.78571

The actual Vapour pressure (Regnault and August and Apjohn) is calculated as:-

$$e = e_{s(w)} - A \times P(td - tw)$$

Where $e_{s(w)}$ is the saturated vapour pressure based on the wet bulb temperature(calculated using the Magnus formular), 'A' is the Ventilation constant and is chosen to suit the instrument type and ventilation rate of the wet sensor. $A=7.99 \times 10^{-4}$ is appropriate to a ventilation rate of 1-1.5m/S assuming the wet bulb >0°.(Ref: MET.O.265b Hygrometric Tables)

'P' is the air pressure measured in mBar, usually this is considered to be a mean value of 1000mB.

Humidity is calculated according to:-

$$RH\% = \frac{e}{e_{s(t)}} \times 100$$

Where 'e' is the vapour pressure and ' $e_{s(t)}$ ' is the saturated vapour pressure calculated using the Magnus equation for the dry bulb temperature.

Dew Point;

The Magnus formula is used to evaluate the dew point temperature assuming a saturated vapour pressure equal to the actual vapour pressure:-

$$Dew Pt^{\circ}C = \frac{[\log_{10} (\text{Vapour}) - \frac{GT_{dew}}{H + T_{dew}} + I]}{[8.2857 - \log_{10} (\text{Vapour})]}$$

WBGT CALCULATION

The WBGT values are calculated within the HSM 100 instrument. They are based upon the following equations-(Ref ISO 7243).

$$\text{WBGT}_{\text{Inside}} = 0.7 \times \text{Wet} + 0.3 \times \text{Globe}$$

$$\text{WBGT}_{\text{Outside}} = 0.7 \times \text{Wet} + 0.2 \times \text{Globe} + 0.1 \times \text{Dry}$$

